



*Jaymart*

**Multitile  
Cleaning &  
Installation  
Guide**

## **Multitile Gymnasium Tiles – Installation**

**Multitile tiles are easy to install as they are simply loose-laid onto a suitably prepared substrate.**

**The tiles are connected using the plastic dowelling rods supplied.**

**The tiles should be connected to each other in lines, and then each line connected to another.**

**As the tiles are 27mm thick, a bevelled edge section should be installed at the edges, or markings applied to denote a step.**

## Multitile Cleaning & Maintenance

**Multitile is a heavy-duty, dense and very durable elastic flooring product. Nevertheless, like with every other product, constant dirt and poor maintenance can cut back the life span and durability substantially.**

**Therefore:**

- 1) Always keep the floor clean of all debris, dirt and sand.**
- 2) Sweep and/or vacuum floor on a regular basis.**
- 3) Weightlayer can be damp mopped using a solution of water and a light detergent.**
- 4) Heavy stains are removed by scrubbing with a nylon brush, using a high concentration of a mild detergent. Wash out with clean water.**
- 5) To enhance the appearance of Blade-Runner, we would suggest that Dr. Schutz Quick Fix is applied to a fully clean floor surface.**

**Caution:**

- 1) Avoid abrasive alkaline or cheap cleaners.**
- 2) Keep surface free of grit, oil, gasoline and acids.**



## QUICK FIX ANTI-SLIP

### 1 PRODUCT DESCRIPTION

Waterbased lacquer providing structure for increased slip-resistant safety.

- Easy to apply, effective in results.
- Good adherence
- Can be removed using Dr Schutz Turbo Strip / Clean and Strip.
- Slip-resistance >36PTV Wet / Dry according to Pendulum Slip Tester BS7976-2 (\*)

### 2 AREAS OF APPLICATION

To be applied on resilient floorings including Vinyl, Linoleum, Wood, Laminate & Resin in areas where a greater slip resistance is requested. Internal use only.

### 3 APPLICATION

- Clean the floor of all grease and contamination using **Dr. Schutz PU Cleaner** or **Clean & Strip** and fully dry.
- Shake up well.
- Use immediately from a roller tray using Dr. Schutz Aquatop or another medium pile roller and apply evenly.

### 4 CONSUMPTION

50 ml/m<sup>2</sup> per coating. 1 litre will cover 20 square meters (200 square feet). 100 square meters (1000 square feet) per 5 liters. For small areas please calculate with additional consumption due to roller (~0,2-0,3l).

### 5 DRYING TIME

Can be carefully walked on after approx. 2 hours. After 24 hours approx. 80% of the durability has been achieved. After 7 days the full durability and chemical resistance of the product is provided (based on conditions of 20 °C, 50% relative humidity and sufficient ventilation). Damp / dry mop only for the first 3 days.

Low temperatures, high humidity and poor ventilation can prolong the drying time. Refrain from laying down carpets in the first 10-14 days. Place furniture carefully.

### 7 STORAGE

Protect against frost. Store in a cool, dry place. Will keep for 24 months in unopened, original canister from the date of manufacture. Keep coating materials out of the reach of children.



## QUICK FIX ANTI-SLIP

### 8 TECHNICAL DATA

Contains substances: water, polyacrylat, silicic acids, waxes, additive. Contains a mixture of: 5-Chlor-2-methyl-2H-isothiazol-3-on and 2 Methyl-2H-isothiazol-3-on. Can cause allergic reactions.

pH 7,5

voc (g/l): <47(ISO 11890)

ADR/RID: not a dangerous good.

CLP: no labelling obligation.

Even when using low-pollution products the usual safety measures are to be observed. Keep out of the reach of children. Completely emptied canisters can be disposed of in domestic waste or at a recycling centre.

### 9 SPECIAL NOTES

(\*) Product tested independently following professional application. Test conducted on the Pendulum Slip Tester method BS7976-2. Certification can be emailed on request.

### 10 CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of Dr. Schutz finishes
- Safety data sheet available on request.

The quoted printed matter, as well as this product information in its updated form, is available on our homepage [www.dr-schutz.com](http://www.dr-schutz.com) or on request from the address quoted below.

#### Dr. Schutz – We Care About Floors

Headquarter  
Dr. Schutz GmbH  
Holbeinstraße 17  
D-53175 Bonn  
Tel.: + 49 228 / 95 35 2-40  
Fax: + 49 228 / 95 35 2-46  
E-Mail: [export@dr-schutz.com](mailto:export@dr-schutz.com)  
[www.dr-schutz.com](http://www.dr-schutz.com)

UK  
Dr. Schutz U.K Ltd.  
Unit 24, Anglo Business Park,  
Smeaton Close, Aylesbury Bucks  
HP19 8UP

Contact: Richard Nelson  
Tel.: 0044 / 1296 437827  
Fax: 0044 / 1296 334219  
E-Mail: [richard@dr-schutz.com](mailto:richard@dr-schutz.com)

Ireland  
Dr. Schutz Ireland  
35 Pic Du Jer Park,  
Ballinlough, Cork

Contact: Paul O'Reardon  
Mobile: 0877678388  
E-Mail: [drschutzireland@gmail.com](mailto:drschutzireland@gmail.com)

North America  
Schutz NA  
4701 Bath St 46, Philadelphia PA  
19137, USA

Contact: Sam Jamison  
Tel.: 001 / 877 272 4889  
Mobile: 001 / 215 510 7874  
E-Mail: [sam@schutzNA.com](mailto:sam@schutzNA.com)

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.



*Jaymart*

**Jaymart Rubber & Plastics  
Limited**

**Roman Way, Crusader  
Park,**

**Warminster**

**BA12 8SP**

**Tel 01985 218994**

**Email: [sales@jaymart.co.uk](mailto:sales@jaymart.co.uk)**

**[www.jaymart.co.uk](http://www.jaymart.co.uk)**